

### 1. View DTC information (Step 1 of 3)

Refresh Clear... Filter -

DTC List (62 Items) Product Time: - Engine Hours: 0 Readout Time: 04/05/2025, 09:48:55

Control Unit	DTC	Status	Count	First Occurrence	Last Occurrence
	Type Information	Inactive	0	20/04/2025, 18:00:52	29/04/2025, 08:52:01
Engine Control Module (EMS)	P021900: Engine Overspeed Condition, No Sub Type Information	Active	1	03/05/2025, 22:01:03	04/05/2025, 09:45:07
Engine Control Module (EMS)	P029900: Turbocharger/Supercharger Underboost, No Sub Type Information	Inactive	1	16/03/2025, 10:20:28	16/03/2025, 10:49:24
Engine Control Module (EMS)	P02E013: Diesel Intake Air Flow Control, Circuit Open	Inactive	231	17/03/2025, 16:50:51	03/05/2025, 22:00:45
Engine Control Module (EMS)	P02E07C: Diesel Intake Air Flow Control, Slow Response	Inactive	77	18/03/2025, 22:33:18	03/05/2025, 22:00:43
Engine Control Module (EMS)	P02E09B: Diesel Intake Air Flow Control, High/Excessive Flow	Active	4	17/03/2025, 16:50:07	02/05/2025, 12:44:20
Engine Control Module (EMS)	P02E697: Diesel Intake Air Flow Position Sensor, Component or System Operation Obstructed or Blocked	Active	2	17/03/2025, 06:08:01	04/05/2025, 01:42:52
Engine Control Module (EMS)	P02E699: Diesel Intake Air Flow Position Sensor, Exceeded Learning Limit	Inactive	2	17/03/2025, 08:46:24	18/03/2025, 09:20:33
Engine Control Module (EMS)	P100713: Air Filter Indicator, Circuit Open	Active	91	24/02/2025, 08:33:02	04/05/2025, 09:45:12
Engine Control Module (EMS)	P100764: Air Filter Indicator, Signal Plausibility Failure	Active	1	19/02/2025, 17:38:53	02/05/2025, 12:13:59

#### Engine Overspeed Condition

1. View DTC information

Continue >

### 1. View DTC information (Step 1 of 3)

Refresh Clear... Filter -

DTC List (62 Items) Product Time: - Engine Hours: 0 Readout Time: 04/05/2025, 09:48:55

Control Unit	DTC	Status	Count	First Occurrence	Last Occurrence
Engine Control Module (EMS)	P100713: Air Filter Indicator, Circuit Open	Active	91	24/02/2025, 08:33:02	04/05/2025, 09:45:12
Engine Control Module (EMS)	P100764: Air Filter Indicator, Signal Plausibility Failure	Active	1	19/02/2025, 17:38:53	02/05/2025, 12:13:59
Engine Control Module (EMS)	P101713: Water In Fuel Drainage Valve, Circuit Open	Inactive	1	20/04/2025, 17:12:56	20/04/2025, 18:00:04
Engine Control Module (EMS)	P108600: Oil Level Moderately Low, No Sub Type Information	Inactive	13	20/02/2025, 02:21:01	20/04/2025, 17:55:33
Engine Control Module (EMS)	P111D00: Engine Coolant Level Moderately Low, No Sub Type Information	Active	42	20/02/2025, 16:02:29	04/05/2025, 09:45:13
Engine Control Module (EMS)	P111E00: Engine Coolant Temperature Moderately High, No Sub Type Information	Inactive	1	18/03/2025, 03:56:50	18/03/2025, 04:01:45
Engine Control Module (EMS)	P115100: Aftertreatment System Over Temperature, No Sub Type Information	Inactive	2	30/04/2025, 16:05:52	30/04/2025, 16:36:55
Engine Control Module (EMS)	P226413: Water in Fuel Sensor, Circuit Open	Inactive	1	20/04/2025, 17:12:54	20/04/2025, 17:22:46
Engine Control Module (EMS)	P256000: Engine Coolant Level Low, No Sub Type Information	Inactive	4	30/04/2025, 11:00:32	30/04/2025, 11:30:21
Front Chassis I/O Module (FCIOM)	C104415: City Horn Circuit, Circuit Short To Battery or Open	Inactive	92	20/02/2025, 05:32:53	03/05/2025, 09:17:34

Engine Overspeed Condition

1. View DTC information Continue >